



M-E 6Bit Adapter


User Manual

Please read the manual carefully before use and save it for future use.

Function button description

Focal length dial

Unlock button



Note

- 1、 When changing the lens, the adapter ring must be separated from the camera body (to identify and read the focal length)
- 2、 When using a lens without the 6Bit function, you need to manually adjust the focal length corresponding to the lens through the dial (28/35/50/75/90/135)
- 3、 When using the TtArtisan 6Bit adapter, the stabilization function of the camera will be turned on automatically.
- 4、 THE Exif recording function cannot be reached on the NEX series camera. The adapter ring only can be used as a full manual adapter.



Instruction Video



Official Web